Tier 4 Final Engine

**Net Power** SAE J1349 / 128 HP (96 kW) at 2,050 rpm Bucket Range 0.39 m³ - 1.05 m³ (0.51 yd³ - 1.37 yd³) Standard Bucket 0.70 m³ (0.92 yd³) Operating Weight 18,830 kg (41,513 lb)

S	HYUNDAI			
	N			1
		AV	Commis	
			160	
			300	

ENGINE				
Make / model			Perkins 1204F	
Туре			Water cooled, 4-cycle diesel, 4 cylinders in line, direct injection, turbo- charged and air cooled	
Rated flywheel	SAF	J1995 (gross)	137 HP (102.1 kW) / 2,050 rpm	
horsepower	SAE	J1349 (net)	128 HP (96 kW) / 2,050 rpm	
Max. torque			57.1 kgf.m (413 lbf.ft) @ 1,400 rpm	
Bore × stroke			105 x 127 mm (4.13" x 5")	
Piston displacement			4,400 cc (268.5 in³)	
Batteries			2 x 12V x 100 Ah	
Starting motor			24 V - 4.5 kW	
Alternator			24 V - 100 Amp	

#### **HYDRAULIC SYSTEM**

#### MAIN PUMP

Type	Two variable displacement piston pumps
Max. flow	2 x 164 l/min (43.3 gpm)
Sub-pump for pilot circuit (Gear Pump)	31.5 l/min (8.3 gpm)

#### CROSS-SENSING AND FUEL-SAVING PUMP SYSTEM

#### **HYDRAULIC MOTORS**

Travel	Two-speed axial pistons motor with brake valve and parking brake
Swing	Axial piston motor with automatic brake

#### **RELIEF VALVE SETTING**

Implement circuits	350 kgf/cm <sup>2</sup> (5,690 psi)	
Travel	350 kgf/cm <sup>2</sup> (5,690 psi)	
Power boost (boom, arm, bucket)	380 kgf/cm² (5,400 psi)	
Swing circuit	285 kgf/cm² (4,054 psi)	
Pilot circuit	40 kgf/cm <sup>2</sup> (570 psi)	
Service valve	Installed	

#### HYDRAULIC CYLINDERS

No. of cylinders bore X stroke	Blade: 2-110 x 320 mm (4.3" x 12.6")
	· · · · · · · · · · · · · · · · · · ·
	2PCS 1st: 2-115 x 960 mm (4.5" x 37.8")
	2nd: 1-160 x 650 mm (6.3" x 25.6")

DRIVES & BRAKES	
Drive method	Fully hydrostatic type
Drive motor	Axial piston motor, in-shoe design
Reduction system	Planetary reduction gear
Max. drawbar pull	17,000 kgf (37,500 lbf)
Max. travel speed (high / low)	5.3 km/hr (3.3 mph) / 3.2 km/hr (2.0 mph)
Gradeability	35° (70%)
Parking brake	Multi wet disc brake

#### CONTRO

Pilot pressure-operated joysticks and pedals with detachable lever provide almost effortless and fatigueless operation.

Pilot control	Two joysticks with one safety lever (LH): Swing and arm (RH): Boom and bucket (ISO)
Traveling and steering	Two levers with pedals
Engine throttle	Electric, dial type

#### **OPERATING WEIGHT (APPROXIMATE)**

Operating weight, including 5,100 mm (16' 9") boom, 3,100 mm (10' 2") arm, SAE heaped 0.70 m³ (0.92 yd³) bucket, lubricant, coolant, full fuel tank, max 3,250 kg (7,165 lb) counterweight and all other standard equipment.

#### **OPERATING WEIGHT**

Shoes		Оре	erating weight	Ground pressure
Туре	Width mm (in)		kg (lb)	kgf/cm² (psi)
Triple	600 (24")	HX160L	18,830 (41,513)	0.46 (6.51)
grouser	700 (28")	HX160L	19,084 (42,073)	0.40 (5.62)

SWING SYSTEM		
Swing motor	Axial pistons motor	
Swing reduction	Planetary gear reduction	
Swing bearing lubrication	Grease-bathed	
Swing brake	Multi wet disc brake	
Swing speed	10.3 rpm	

SERVICE REFILL CAPACITIES			
Refilling	liters	US gal	
Fuel tank	290	76.6	
Engine coolant	27.5	7.3	
Engine oil	10.5	2.8	
Swing device	6.2	1.6	
Final drive (each)	3.0	0.8	
Hydraulic system (including tank)	240	63.4	
Hydraulic tank	125	33.0	
DEF/AdBlue® tank	19	5	

#### UNDERCARRIAGE


The X-leg type center frame is integrally welded with reinforced box-section track frames. The undercarriage includes lubricated rollers, idlers, track adjusters with shock absorbing springs and sprockets, and a track chain with double or triple grouser shoes.


Center frame	X - leg type
Track frame	Pentagonal box type
No. of shoes on each side	49 EA
No. of carrier rollers on each side	2 EA
No. of track rollers on each side	7 EA
No. of rail guards on each side	1 EA

Tier 4 Final Engine

#### HX160L DIMENSIONS Unit: mm (ft·in)


5.1 m (16' 9") boom and 2.2 m (7' 3"), 2.6 m (8' 6"), 3.1 m (10' 2") arm





	Boom length		5,100 (16' 9")	
	Arm length	2,200 (7' 3")	2,600 (8' 6")	3,100 (10' 2")
J	Overall length	8,660 (28' 5")	8,650 (28' 5")	8,650 (28' 5")
K	Overall height of boom	3,010 (9' 11")	2,990 (9' 10")	3,150 (10' 4")
L	Track shoe width	500 (20")	600 (24")	700 (28")
М	Overall width	2,490 (8' 2")	2,590 (8' 6")	2,690 (8' 10")


HX160L WORKING RANGE			Unit : mm (ft·in)
Boom length		5,100 (16' 9")	
Arm length	2,200	2,600	3,100
	(7' 3")	(8' 6")	(10' 2")
A Max. digging reach	8,690	9,020	9,450
	(28' 6")	(29' 7")	(31' 0")
A' Max. digging reach on ground	8,530	8,860	9,300
	(28' 0")	(29' 1")	(30' 6")
B Max. digging depth	5,660	6,060	6,560
	(18' 7")	(19' 11")	(21' 6")
B' Max. digging depth (8' level)	5,430	5,850	6,370
	(17' 10")	(19' 2")	(20' 11")
C Max. vertical wall digging depth	5,120	5,380	5,710
	(16' 10")	(17' 8")	(18' 9")
D Max. digging height	8,750	8,840	8,980
	(28' 8")	(29' 0")	(29' 6")
E Max. dumping height	6,110	6,220	6,390
	(20' 1")	(20' 5")	(21' 0")
F Min. swing radius	3,180	3,170	3,170
	(10' 5")	(10' 5")	(10' 5")



DIGGING F	ORCE					
Arm	Length	mm (ft·in)	2,200 (7' 3")	2,600 (8' 6")	3,100 (10' 2")	
AIIII	Weight kg (lb) 750 (1,560)	810 (1,790)	890 (1,960)			
		kN	107.9 [117.2]	107.9 [117.2]	107.9 [117.2]	
	SAE	kgf 11,000 [11,940] 11,000 [11,940]	11,000 [11,940]			
Bucket		lbf	24,250 [26,330]	24,250 [26,330]	24,250 [26,330]	
digging force		kN	123.6 [134.2]	123.6 [134.2]	123.6 [134.2]	
10166	ISO	kgf	12,600 [13,680]	12,600 [13,680]	12,600 [13,680]	[Power
		lbf	27,780 [30,160]	27,780 [30,160]	27,780 [30,160]	Boost]
		kN	87.2 [94.7]	77.3 [83.9]	69.0 [74.9]	
	SAE	kgf	8,890 [9,650]	7,880 [8,560]	7,030 [7,630]	
Arm		lbf	19,600 [21,280]	17,370 [18,860]	15,500 [16,830]	
crowd force		kN	91.0 [98.8]	80.3 [87.2]	71.4 [77.5]	
. 31 66	ISO	kgf	9,280 [10,080]	8,190 [8,890]	7,280 [7,900]	
		lbf	20,460 [22,210]	18,060 [19,600]	16,050 [17,430]	

Note: Arm weight includes bucket cylinder, linkage, and pin

Tier 4 Final Engine



### **Lifting Capacity**

Boom: 5,100 mm (16' 9")

Capacities based on North American Standard Configuration in accordance with ISO condition 2 standard.

Arm: 3,100 mm (10' 2")

Bucket: 0.70 m<sup>3</sup> (0.92 yd<sup>3</sup>) SAE heaped

Rating over front Rating over side or 360 degree

Shoe: 600 mm (24") triple grouser CWT 3 250 kg (7 165 lb)

						Lift-poir	nt radius					At	t max. reach	
Lift-point height m (ft)		1.5 m (4.9 ft)		3.0 m (9.8 ft)		4.5 m (	4.5 m (14.8 ft) 6.0 m (19.7 ft)		19.7 ft)	7.5 m (24.6 ft)		Capacity		Reach
				<b>F</b>								<b>P</b>		m (ft)
6.0 m	kg							*3,810	3,790			*2,850	*2,580	6.78
(19.7 ft)	lb							*8,400	8,360			*6,290	*6,290	(22.2)
4.5 m	kg							*4,360	3,730	*2,980	2,590	*2,760	2,560	7.55
(14.8 ft)	lb							*9,600	8,210	*6,560	5,700	*6,080	5,630	(24.8)
3.0 m	kg			*9,340	*9,340	*6,570	5,490	*5,470	3,580	3,910	2,540	*2,800	2,300	7.97
(9.8 ft)	lb			*20,590	*20,590	*14,490	12,110	*12,070	7,900	8,620	5,600	*6,180	5,060	(26.1)
1.5 m	kg			*7,940	*7,940	*8,260	5,130	5,350	3,410	3,830	2,460	*2,970	2,200	8.09
(4.9 ft)	lb			*17,500	*17,500	*18,200	11,300	11,790	7,530	8,440	5,430	*6,560	4,840	(26.5)
Ground	kg			*7,130	*7,130	8,040	4,870	5,200	3,280	3,760	2,400	*3,310	2,230	7.91
Line	lb			*15,710	*15,710	17,720	10,740	11,460	7,230	8,290	5,290	*7,300	4,910	(26.0)
-1.5 m	kg	*5,530	*5,530	*10,100	8,740	7,910	4,760	5,120	3,210			3,780	2,410	7.43
(-4.9 ft)	lb	*12,200	*12,200	*22,280	19,280	17,440	10,490	11,280	7,070			8,340	5,310	(24.4)
-3.0 m	kg	*9,310	*9,310	*13,130	8,830	7,920	4,770	5,130	3,220			4,520	2,860	6.57
(-9.8 ft)	lb	*20,530	*20,530	*28,950	19,470	17,460	10,520	11,310	7,090			9,970	6,310	(21.6)
-4.5 m	kg			*10,050	9,080	*6880	4,910					*5,640	4,110	5.14
(-14.8 ft)	lb			*22,160	20,010	*15,170	10,830					*12,430	9,050	(16.9)

#### NOTES:

- 1. Lifting capacities are based on ISO 10567.
- 2. Lifting capacity of the HX Series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.
- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. (\*) indicates load limited by hydraulic capacity.



Tier 4 Final Engine

Perkins 1204F Engine HYDRAULIC SYSTEM  Intelligent Power Control (IPC) 3-power mode, 2-work mode, user mode Variable power control Pump flow control Attachment mode flow control Engine auto idle Engine auto idle Engine auto shutdown control Electronic fan control  CAB & INTERIOR  ISO standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover  Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Fuel warmer Warnings Communication error	NGINE	STD	OPT
Intelligent Power Control (IPC) 3-power mode, 2-work mode, user mode Variable power control Pump flow control Attachment mode flow control Engine auto side Engine auto side Engine auto side Electronic fan control Electronic fan control Electronic fan control  CAB & INTERIOR STD ISO standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (IH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin inforts Cabin front window rain guard Cabin roof-steel cower Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel warmer Warnings • •	erkins 1204F Engine	•	
3-power mode, 2-work mode, user mode  Variable power control Pump flow control Attachment mode flow control Engine auto idle Engine auto shutdown control Electronic fan control Electronic fan control  Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side-in front window Sliding side-in front window Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin finght window rain guard Cabin roof-steel cover  Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings  • Pan Warnings	HYDRAULIC SYSTEM		
Variable power control Pump flow control Attachment mode flow control Engine auto idle Engine auto shutdown control Electronic fan control  CAB & INTERIOR STD  ISO standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin Infront window arin guard Cabin roof-steel cover  Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power  Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings  • Carrivacings			
Pump flow control Attachment mode flow control Engine auto idle Engine auto shutdown control Electronic fan control  CAB & INTERIOR  STD  ISO standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power  Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings  • Warnings	3-power mode, 2-work mode, user mode	•	
Attachment mode flow control Engine auto idle Engine auto shutdown control Electronic fan control  CAB & INTERIOR  STD  ISO standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings  • Caveraurics Fuel warmer  Low Warnings		•	
Engine auto idle Engine auto shutdown control Electronic fan control  CAB & INTERIOR  STD  ISO standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings  • Campartings • Campartings • Campartings • Campartings • Campartings		•	
Engine auto shutdown control Electronic fan control  CAB & INTERIOR  STD  ISO standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic Climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel warmer  Varnings  • EVAPORTORION  • CABINITERIOR  STD  STD  STD  STD  STD  STD  STD  ST		•	
Electronic fan control  CAB & INTERIOR  ISO standard cabin  Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB  Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin Iights Cabin front window rain guard Cabin roof-steel cover  Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather  Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer  Varnings		•	
ISO standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Vernings			•
Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel warmer  Varnings	Electronic fan control	•	
Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility	CAB & INTERIOR	STD	OPT
Radio / USB player Bluetooth / hands-free mobile phone system with USB  Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* 'LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel warmer  Warnings	SO standard cabin		
Bluetooth / hands-free mobile phone system with USB Miracast 24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover  Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather  Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine speed or trip meter / accel. Engine speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings	Rise-up type windshield wiper	•	
Miracast 24V DC to 12V DC converter Electric horn Electric horn All-weather steel cab with 360° visibility  Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings	Radio / USB player	•	
24V DC to 12V DC converter Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings	Bluetooth / hands-free mobile phone system with USB	•	
Electric horn  All-weather steel cab with 360° visibility  Safety glass windows  Sliding fold-in front window Sliding side window (LH)  Lockable door  Hot and cool box Storage compartment and ashtray  Transparent cabin roof cover Sun visor  Door and cab locks, one key  Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover  Automatic climate control  Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather  Centralized monitoring  8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Varnings	Miracast	•	
All-weather steel cab with 360° visibility  Safety glass windows  Sliding fold-in front window  Sliding side window (LH)  Lockable door  Hot and cool box  Storage compartment and ashtray  Transparent cabin roof cover  Sun visor  Door and cab locks, one key  Mechanical suspension seat with heater  Pilot-operated adjustable joystick  Console box height adjust system  Cabin lights  Cabin front window rain guard  Cabin roof-steel cover  Automatic climate control  Air conditioner and heater  Defroster  Starting aid (air grid heater) for cold weather  Centralized monitoring  8° LCD display  Engine speed or trip meter / accel.  Engine coolant temperature gauge  Max. power  Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge  Fuel warmer  Warnings	24V DC to 12V DC converter	•	
Safety glass windows  Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings	Electric horn	•	
Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings		•	
Sliding side window (LH)  Lockable door  Hot and cool box  Storage compartment and ashtray  Transparent cabin roof cover  Sun visor  Door and cab locks, one key  Mechanical suspension seat with heater  Pilot-operated adjustable joystick  Console box height adjust system  Cabin lights  Cabin front window rain guard  Cabin roof-steel cover  Automatic climate control  Air conditioner and heater  Defroster  Starting aid (air grid heater) for cold weather  Centralized monitoring  8" LCD display  Engine speed or trip meter / accel.  Engine coolant temperature gauge  Max. power  Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge  Fuel warmer  Warnings	7,5	•	
Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings		•	
Hot and cool box  Storage compartment and ashtray  Transparent cabin roof cover  Sun visor  Door and cab locks, one key  Mechanical suspension seat with heater Pilot-operated adjustable joystick  Console box height adjust system  Cabin lights  Cabin front window rain guard  Cabin roof-steel cover  Automatic climate control  Air conditioner and heater  Defroster  Starting aid (air grid heater) for cold weather  Centralized monitoring  8" LCD display  Engine speed or trip meter / accel.  Engine coolant temperature gauge  Max. power  Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges Fuel level gauge  Hydraulic oil temperature gauge  Fuel warmer  Warnings	3 17	•	
Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings		_	
Transparent cabin roof cover  Sun visor  Door and cab locks, one key  Mechanical suspension seat with heater  Pilot-operated adjustable joystick  Console box height adjust system  Cabin lights  Cabin front window rain guard  Cabin roof-steel cover  Automatic climate control  Air conditioner and heater  Defroster  Starting aid (air grid heater) for cold weather  Centralized monitoring  8" LCD display  Engine speed or trip meter / accel.  Engine coolant temperature gauge  Max. power  Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge  Fuel warmer  Warnings		•	
Sun visor  Door and cab locks, one key  Mechanical suspension seat with heater  Pilot-operated adjustable joystick  Console box height adjust system  Cabin lights  Cabin front window rain guard  Cabin roof-steel cover  Automatic climate control  Air conditioner and heater  Defroster  Starting aid (air grid heater) for cold weather  Centralized monitoring  8" LCD display  Engine speed or trip meter / accel.  Engine coolant temperature gauge  Max. power  Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge  Fuel warmer  Warnings			
Door and cab locks, one key  Mechanical suspension seat with heater  Pilot-operated adjustable joystick  Console box height adjust system  Cabin lights  Cabin front window rain guard  Cabin roof-steel cover  Automatic climate control  Air conditioner and heater  Defroster  Starting aid (air grid heater) for cold weather  Centralized monitoring  8" LCD display  Engine speed or trip meter / accel.  Engine coolant temperature gauge  Max. power  Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge  Warnings	<del></del>	•	
Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings		•	
Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings			
Console box height adjust system Cabin lights Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings			
Cabin lights Cabin front window rain guard Cabin roof-steel cover  Automatic climate control  Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather  Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings		•	
Cabin front window rain guard Cabin roof–steel cover Automatic climate control  Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings		•	
Cabin roof–steel cover  Automatic climate control  Air conditioner and heater • Defroster • Starting aid (air grid heater) for cold weather  Centralized monitoring  8" LCD display • Engine speed or trip meter / accel. • Engine coolant temperature gauge • Max. power • Low speed / high speed • Auto idle • Overload • Check engine Air cleaner clogging • Indicators • ECO gauges • Fuel level gauge • Hydraulic oil temperature gauge • Fuel warmer • Varnings		•	
Automatic climate control  Air conditioner and heater  Defroster  Starting aid (air grid heater) for cold weather  Centralized monitoring  8" LCD display  Engine speed or trip meter / accel.  Engine coolant temperature gauge  Max. power  Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge  Fuel warmer  Warnings			•
Air conditioner and heater  Defroster  Starting aid (air grid heater) for cold weather  Centralized monitoring  8" LCD display  Engine speed or trip meter / accel.  Engine coolant temperature gauge  Max. power  Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge  Warnings			•
Defroster Starting aid (air grid heater) for cold weather  Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings			
Starting aid (air grid heater) for cold weather  Centralized monitoring  8" LCD display  Engine speed or trip meter / accel.  Engine coolant temperature gauge  Max. power  Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges Fuel level gauge  Hydraulic oil temperature gauge  Warnings			
Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings			
8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings		-	
Engine speed or trip meter / accel.  Engine coolant temperature gauge  Max. power  Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge  Fuel warmer  Warnings	5		
Engine coolant temperature gauge  Max. power  Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge  Fuel warmer  Warnings			
Max. power  Low speed / high speed  Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings			
Low speed / high speed  Auto idle  Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge Fuel warmer  Warnings		_	
Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings  • • • • • • • • • • • • • • • • • •		_	
Overload  Check engine  Air cleaner clogging  Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge  Fuel warmer  Warnings			
Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings  •  •  Warnings			
Air cleaner clogging Indicators  EC O gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer  Warnings  •  •  •  •  •  •  •  •  •  •  •  •  •			-
Indicators  ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge Fuel warmer  Warnings  •  •  •  •  •  •  •  •  •  •  •  •  •			
ECO gauges  Fuel level gauge  Hydraulic oil temperature gauge Fuel warmer  Warnings  •  •  •  •  •  •  •  •  •  •  •  •  •			
Fuel level gauge Hydraulic oil temperature gauge Fuel warmer  Warnings  •  •  •  •  •  •  •  •  •  •  •  •  •			
Hydraulic oil temperature gauge Fuel warmer  Warnings  •			
Fuel warmer • Warnings •			
Warnings •			
		•	
Low battery •		•	
Clock		•	

CAB & INTERIOR		STD	OPT
Seat			
Adjustable air suspension seat with heat	er	•	
Cabin FOG/FOPS FOG ISO 10262 Level 2	Frant and ton guard		
(FOPS ISO 3449 Level 2)	Front and top guard Top guard		•
Cabin ROPS	10p guara		
ROPS ISO 12117-2		•	
SAFETY		STD	ОРТ
Battery master switch			
Rearview camera		•	
AAVM (All-Around View Monitoring)			•
Four front working lights (2 boom mounted	ed, 2 front frame mounted)	•	
Travel alarm		•	
Rear work lamp			•
Beacon lamp Automatic swing brake			•
Boom holding system		•	
Arm holding system		•	
Safety lock valve for boom cylinder with overlo	oad warning device		•
Safety lock valve for arm cylinder			•
Swing lock system			•
Three outside rearview mirrors		•	
OTHER		STD	OPT
Booms			
5.1 m, 16' 9"		•	
5.1 m, 16' 9" 2-piece			•
Arms			
2.2 m, 7' 3" 2.6 m, 8' 6"			•
3.1 m, 10' 2"		•	-
Removable clean-out dust net for cooler		•	
Removable reservoir tank		•	
Fuel pre-filter		•	
Fuel warmer			•
Self-diagnostics system	N. 1. 1.	•	
Hi-Mate Remote Management System	Mobile Satellite	•	
Batteries (2 x 12V x 100 Ah)	Satellite		_
Fuel-filler pump (50 l/min / 13 gpm)			•
Single-acting piping kit (breaker, etc.)			•
Double-acting piping kit (clamshell, etc.)		•	
Rotating piping kit			•
Quick coupler piping		•	
Quick coupler  Boom float control		1	•
Pilot accumulator			-
Pattern change valve (SAE and ISO)		•	
Fine swing control system			•
Tool kit			•
UNDERCARRIAGE		STD	ОРТ
Lower frame under cover (additional)			•
Lower frame under cover (normal)		•	
Track shoes		· .	
Triple grouser shoes (600 mm, 24")		•	
Triple grouser shoes (700 mm, 28")			•
Triple grouser shoes (500 mm, 20")			•
Track rail guard		•	_
Full track rail guard			•

NOTE: Standard and optional equipment may vary. Materials and specifications are subject to change without advance notice. Contact your Hyundai dealer for more information.



www.hceamericas.com 6100 Atlantic Blvd., Norcross, GA 30071 TEL (678) 823 7777 FAX (678) 823 7778

PLEASE CONTA	CT		

Made in the U.S.A. 1046-EX-SP 2/2018v7